

RL-F970 LI-ION RECHARGEABLE BATTERY

USER MANUAL




Thank you for choosing our product. Please read this manual carefully before operating and save it for future reference.

Features

- SONY NP-F970 compatible battery.
- Featured with high-precision detection function on battery voltage.
- Multi protection from over charge, over discharge and short circuit.

Appearance



Technical Specifications

Model	RL-F970
Voltage	7.2V
Capacity	47.5Wh, 6600mAh
Output	Electrode port
Input	Electrode port
Dimensions	70*38*60mm
Weight	200g
Applicable Cameras	SONY CCD-TR series, DCR-TRV(MINIDV) series, DCR-VX(MINIDV) series, INFOLITHIUM series, HXR-MC1500C, NEX-FS700CK, NEX-EA50, HXR-MC2500C, HXR-NX5C, FDR-AX1E-BC, DSR-PD198P, DSR-190P, DSR-PD190P, DSR-PD100P, DSR-V10, DX-1000, etc. Compatible with SONY NP-F970 series batteries

Charging instructions

- Snap the battery into the battery compartment of the device, and use the battery electrodes to supply power.

Attention

- Even when fully charged, the battery will still experience self-discharge while in storage.
- It is normal for the battery to generate some heat while charging and in use.
- Do not use the battery in high temperature environment above 60 °C.
- Keep the electrodes clean and do not allow short circuits between the electrodes.
- Store the battery in a cool, dry place. Charge the battery to above 50% capacity before long-term storage, and recharge it every three months to maintain its health.

Warning

- Do not leave the battery at a high temperature (140 °F / 60 °C).
- Do not throw the battery into fire or burn it.
- Do not disassemble without permission.
- Use the recommended charger.
- Avoid heavy hits.

Warranty

Warranty rules

- Our company warrants its Batteries to be free from defects in material and workmanship under normal use in accordance with the specifications and instructions as specified in the user manual for a period of 2 (two) years from the date of purchase.

Please note the following circumstances are not within the scope of free maintenance.

- Product malfunction or damage caused by failure to install, use, maintain or store according to the instructions.
- Alteration / tearing off of product labels, or product damage caused by disassembly / maintenance without authorization.
- The warranty period has expired.
- Product damage due to force majeure factors (such as earthquake, flood, fire, lightning strike, etc.) or artificial damage.

Disclaimer

Our company does not assume any responsibility for equipment damage or safety incident caused by failure to follow instructions in this USER MANUAL.

NANJING YINGCHEN PRO-VIDEO EQUIPMENT CO., LTD.

Building A2, No. 219 Lantian Road, Lukou Subdistrict, Jiangning District, Nanjing

Tel: 025-52151907 Fax: 025-52151907

www.yinchem.cn